Life Saving Appliance



LIFEBOAT & ASSEMBLY STATION



4690 G, 4690 L



4693 G, 4693 L



4680 G, 4680 L



4683 G, 4683 L




4699 G, 4699 L



4694 G, 4694 L



4688 G, 4688 L




4681 G, 4681 L



4691 G, 4691 L



4692 G, 4692 L



4684 G, 4684 L



4685 G, 4685 L



4695 G, 4695 L



4696 G, 4696 L



4686 G, 4686 L




4687 G, 4687 L



4026 Q



4871 G



4410 Q



4621 G



4026 C

4410 C

Assembly Station & Embarkation

Use letters or numbers to identify assembly or embarkation stations and place them on the right hand side of the safety sign.



4871 P 4871 G



4872 P 4873 P 4872 G 4873 G



4874 G

4874 P 4875 P

4875 G




4876 P

4876 G



4877 P 4878 P 4877 G 4878 G



4621 P

4621 P

4621 G

4622 P

4622 G

4623 P

4623 G

4624 P

4624 G

4625 P

4626 G

4627 P

4627 G

4628 P

4628 G

4629 P 4629 G



4620 P 4620 G

Assembly Station has the same meaning as Muster Station. Assembly / Embarkation Stations should be identified with the appropriate sign with an identification number or letter on the right side of the sign. Direction to Assembly / Embarkation Stations can be marked using the Assembly / Embarkation sign with a Direction Arrow.

4625 G

